



## External dimension

Controller



## Installation on a panel inside a metal control box

Controller mounting hole



## Installation on a DIN rail

